



Backset Guide

Above is a template you can use for helping measure your current door or drill your door for a new deadbolt/knob lock. All deadbolts we sell include a guide similar to the one above in the box, so you do not need to use this one if you are planning to drill your door.

To use the guide first measure the rulers above to make sure they are actually 15cm/6" long. This will ensure your printer properly printed this document without shrinking or stretching it. Once you have verified it printed properly you should fold on the fold here line and then apply it to your door. For more details please contact us.